




TR-14				
ITEM	QTY	PART NUMBER	DESCRIPTION	
1	1	T-12-600R	RING HITCH	
2	1	H-7M8-10	YOKE ASM.	
3	1	H-7M2-10	LEG ASM.	
4	2	H-7M9-10	LEG ASM.	
5	2	1/2-13 X 3	BOLT	
6	8	1/2-13	LOCK NUT	
7	10	9/16	WASHER	
8	3	1/2-13 X 3 1/2	BOLT	
9	20	5/16	WASHER	
10	10	5/16 - 24	NUT	
11	8	5/16-18 X 1	BOLT	
12	1	HM-100	CASTER WHEEL	
13	3	5/16-18 X 3	BOLT	
14	1	BALL HITCH	BALL HITCH	
15	1	H-6M5-00	HANDLE ASM.	
16	1	1/16 X 1	COTTER PIN	
17	1	T44-01-00L	END ASM. LEFT	
18	1	T44-01-00R	END ASM. RIGHT	
19	2	T44-02-00	PIN	
20	1	T44-03-00A	SPREADER TUBE	
21	6	TR6-09	PLATE	
22	1	92627A117	PIN	
23	12	1/4	WASHER	
24	12	1/4-28 X 3	BOLT	
25	12	1/4	WASHER	
26	12	1/4-28	NUT	
27	2	5/16	WASHER	
28	1	5/16-18	NUT	
29	4	3/8	WASHER	
30	2	3/8-16 X 2 3/4	BOLT	
31	2	3/8-16	NUT	
32	2	90222A112	LOCKING PIN ASSEMBLY	
33	2	W-2.80 X 4 TW	TIRE WHEEL ASSEMBLY	
34	4	1/2	WASHER	
35	2	1/2-13 X 6	BOLT	